



# Interphase

## Gel Foundation: High Spreadability, High viscosity

Formulation 00838

### ATTRIBUTES

- Cold Processing
- Smooth skin feel
- Very comfortable to wear
- High Spreadability
- High viscosity

### DOW CORNING® PRODUCTS

- DOW CORNING® 5200 FORMULATION AID
- DOW CORNING® 9701 COSMETIC POWDER
- DOW CORNING® BY 11-030

### XIAMETER® PRODUCTS

- XIAMETER® PMX-0245 CYCLOPENTASILOXANE
- XIAMETER® PMX-1184 SILICONE FLUID

Ingredient	Wt. %	Trade Name/Supplier
Phase A		
1. Cyclopentasiloxane	38.43	XIAMETER® PMX-0245 CYCLOPENTASILOXANE
2. Lauryl PEG/PPG-18/18 Methicone	1.5	DOW CORNING® 5200 FORMULATION AID
3. Cyclopentasiloxane and PEG/PPG-19/19 Dimethicone	23.5	DOW CORNING® BY 11-030
4. Dimethicone (and) Trisiloxane	7.6	XIAMETER® PMX-1184 SILICONE FLUID
5. Isononyl Isononanoate	7.6	Isononyl Isononanoate / Sensient
6. Phenoxyethanol (and) Methylparaben (and) Ethylparaben (and) Butylparaben (and) Isobutylparaben (and) Propylparaben	0.3	Dekaben / Jan Dekker
Phase B		
7. CI 77499 (and) Triethoxycaprylylsilane	0.2	Unipure Black LC 989 AS-EM / Sensient
8. CI 77891 (and) Triethoxycaprylylsilane	4.4	Unipure White LC 981 AS-EM / Sensient
9. CI 77492 (and) Triethoxycaprylylsilane	0.9	Unipure Yellow LC 182 AS- EM / Sensient
10. CI 77491 (and) Triethoxycaprylylsilane	0.4	Unipure Red LC 381 AS-EM / Sensient
11. Cyclopentasiloxane	5.9	XIAMETER® PMX-0245 CYCLOPENTASILOXANE
Phase C		
12. Dimethicone/Vinyl Dimethicone Crosspolymer (and) Silica	7.1	DOW CORNING® 9701 COSMETIC POWDER
13. Mica (and) Iron Oxides (and)	0.5	Lumiral / Sensient

Titanium Dioxide		
14. Silica Dimethyl Silylate	1	Covasilic 15 / Sensient
Phase D		
15. Water	0.67	

#### Procedure

1. Mix phase A ingredients together until all ingredients are completely dissolved.
2. Premix the pigments in DC 245 using Ultra-Turrax, homogenize until uniform
3. Add phase B to phase A and homogenize.
4. Mix phase C ingredients together.
5. Add phase C to AB blend, slowly and with turbulent mixing.
6. Continue to stir for 1 hour at 1400 rpm.
7. Homogenize using a high shear mixer.
8. Add phase D under stirring, and reduce the stirring speed (formulation will rapidly increase viscosity). Continue to stir for additional 5-10 minutes. Final viscosity is around 35.000-40.000 cps (Spn7, 20 rpm)

#### Variations

Alternative Dow Corning® Products have not been tested as of this printing.

#### Stability

Stable for at least 3 months at room temperature and 40°C.

#### External Reference Material

Color your world

#### Dow Corning® Application Patents

---

This suggested formulation is only a representative formulation and it is not a commercialized product. Dow Corning believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. In addition, Dow Corning has not undertaken a comprehensive patent search on the formulation. Suggestions of uses should not be taken as inducements to infringe any particular patent.

SAFE HANDLING INFORMATION  
 PRODUCT SAFETY INFORMATION REQUIRED FOR SAFE USE IS NOT INCLUDED.  
 BEFORE HANDLING, READ PRODUCT AND MATERIAL SAFETY DATA SHEETS AND CONTAINER LABELS FOR SAFE USE, PHYSICAL AND HEALTH HAZARD INFORMATION. FOR THE MATERIAL SAFETY DATA SHEET PLEASE SEE OUR WEB SITE, DOWCORNING.COM, OR CONSULT YOUR LOCAL DOW CORNING REPRESENTATIVE.

*Dow Corning* is a registered trademark of Dow Corning Corporation.  
 XIAMETER is a registered trademark of Dow Corning Corporation.

© 2010 Dow Corning Corporation. All rights reserved.